

Pebble Tile Installation Guide



1. SPREAD AND COMB MIXED THINSET to an area not more than 8 square feet at a time.



3. GENTLY TAPE DOWN THE TILE it is important that each pebble is embedded in thinset.




5. WAIT 15 MINUTES OR FOLLOW THE INSTRUCTIONS, remove exceeding grout with a sponge, repeat sponging off until desire finish is reached.



2. SET THE TILE in thinset, cut the tile to fit the edge, make sure the tile joints fit tightly.



4. APPLY GROUT all over the tiles.



6. SEAL THE TILES AFTER the grout has been completely cured.

Standing Pebble Tile Installation Guide



1. SPREAD AND COMB MIXED THINSET to an area not more than 8 square feet at a time.



3. GENTLY TAPE DOWN THE TILE it is important that each pebble is embedded in thinset.



5. SEAL THE TILES WITH professional-grade sealant following instructions.



2. SET THE TILE IN THINSET it is crucial to alternate and stagger the pieces in each row so that seams do not line up from one row to the next.



4. USE A GROUT BAG TO FILL spots where mesh may be seen from top.

