

Installation Instructions



Step 1: Install the casters (wheels) to the cabinet bottom. If there are no pre-holes, determine the correct position and secure them directly with screws.



Step 2: Install the glass hanging supports.



Step 3: Secure the vertical main panels to the bottom base with screws, as shown.



Step 4: Once all the lower panels are secured, attach the top panel to the main panels with screws, one by one.



Step 5: Fix the cabinet door handles to finish the assembly.