



Complete Accessories



Step 1 : Install the foot pad



Step 2 : Link the pull rod with white screws



The small hole on the pull rod faces upward



Use yellow screws to screw from the bottom to the top



The top plate is also installed in the same way



Installation is completed