



ASSEMBLY INSTRUCTION

DESCRIPTION : 2 DOOR SHOE CABINET

HARDWARE	A	B	C	D	E	F	G	H	I	J	K		
WOOD DOWEL M8 X 25MM	B1 MINIFIX 5654+5546	B2 QUICKFIT CAP	B3 CB SCREW M3.5X16MM	16MM CSK CAP M6X50MM	50MM NAIL 5/8	SHELF SUPPORT	G1 HANDLE 7050	G2 HANDLE SCREW M4X19MM	G3 WASHER	HINGES 5/8	ALLEN KEY M4	2 PIN STOPPER	5038 PVC SQUARE LEG
8	4 SETS		32	4	16	8	2	4	4	4	1	1	4

