



## C190923



Please read these instructions and warranty information carefully before use and keep them properly for future reference.

## OPERATING INSTRUCTIONS

No.	Picture	Qty.	Size	No.	Picture	Qty.	Size
1		2	147. 7	10		1	98. 2
2		2	147. 7	11		1	98. 2
3		1	172	12		1	164.3
4		1	172	13		1	164.3
5		4	130. 3	14		1	165.8
6	-	2	147. 7	15		1	165.8
7		2	147. 7	16		8	130
8		1	98. 2			6	96. 9
9		1	98. 2	17			,



34		2		A		10	3.8*133. 5*58.8
36	Ť	4		В		9	3.8*99* 58.8
37	Û	2		С		2	3.8*129. 6*58.3
38		8		D		1	3.8*129. 6*58.3
39		56		E		2	3.8*36* 56
40		1		F	$\bigcirc$	1	3.8*53.5 *58.3
41		8		0			3.8*129.
42		4		G		2	6*53.1
43		32	I				
Н			2		3.8*34.5*53.3		
I			1		3.8*19.7*63		
J			1		3.8*37.5*58.3		
к			2		3.8*77.6*57.6		
44	<u> </u>	4					
45	4 40		Ď			4	





Step 2 : :put 12 and 13 connect with 3 by screw



Step 3: slide PC panel G into groove 5 and 12 13



Step 4: connect 19 with 5 by screw 39





:



Step 6: Connect 8 with 9 by plastic connector 34, then connect 8,9 with 5 by connector 33-1/33-2



Step 7: Slide PC panel I into grooves of 8,9 ,then connect 21 with 12 and 13, then tighten the screws



Step 8: The door: Connect 25 and 27 by plastic connector ; slide one PC panel K into the groove of 27and 28; slide 28 with its groove to connect with K; then slide the other K into the groove of 26, 28 and 29



Step 9: According to the above step, assemble other side of greenhouse



Step 10 :stand greenhouse, connect 1,2 with front and back by connector 32



Step 11: connect 6,7 with both ends of 5 by plastic connector 33-1/33-2



Step 13: connect 2 parts 23 by screw 42



Step 13: Connect both ends of 23 with 8,9/10,11 by plastic connector 34; slide the window into the groove of 23;



Step 14: Connect 23 with plastic connector 34 by screw 42



Step15: :Connect 16,17,18 with 6 ,7, 23 by screws, but keep the screws loose for later PC panels assembly; then connect 18 with 24





Step 16: Slide PC panels A(the wall), B(the roof), and J(the roof) into the grooves of 17and 18, then tighten the screws.



Step 17: Connect 36 with 31 by screw 40; then connect dewatering profile with 6,7 by screw; Connect 31 with 6,7 by screw 38;



Step 18 : Push the plastic cover onto the top plastic connector.



Put 44 on inside 4 base corner, then connect screw 46 and 45 fixed in to the floor



Finish



In the end, In order to enhance the fastness of greenhouse, adjust the screws.



001-877-644-9366 customerservice@aosom.com



001-855-537-6088 customerservice@aosom.ca



0044-800-240-4004 enquiries@mhstar.co.uk



0049-(0)40-88307530 service@aosom.de



0033-1-84166106 contact@aosom.fr



0034-931294512 atencioncliente@aosom.es



0039-0249471447 clienti@aosom.it

