

## ASSEMBLY INSTRUCTIONS



**Description:** PENDANT

These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

**We strongly suggest that all hard wired fixtures be installed by a professional electrician.**

### ***Parts Included:***

1. Main Body
2. Mounting Spider
3. Canopy set
4. Glass (01 Pcs)
5. Metal Pipe(2pcs-12" & 1 pc-6")

### ***Hardware Enclosed:***

1. (2) Mounting Screws
2. (2) Plastic Wire Connectors
3. (1) Green ground screw
4. (1) Allen Key

### ***To Install You Will Need:***

1. 2 people recommended (Not Provided)
2. Phillips Screwdriver (Not Provided)
3. Electrical tape (Not Provided)
4. Wire cutters (Not Provided)

### ***To Assemble:***

1. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
2. Included are (1) 6" pipe and (2) 12" pipes. Determine which of these you will need to reach your desired length. At least (1) 6" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the threaded part of the pipes toward the ceiling.
3. Screw each pipe to each other starting with the one closest to the Main Body and moving upwards to the canopy.
4. There is an Allen screw with each pipe and which should be tightened with the help of Allen wrench included with the hardware once pipes are assembly with each other as per desired height.
5. Shut off the main electrical supply from the main fuse box/circuit breaker.
6. Gently pull wiring down from ceiling junction box and allow to hang.
7. Open/ unscrew the bush just below the canopy.
8. Remove mounting spider from the canopy by unscrewing the collar. Let the Canopy fall down.
9. Then you will find Mounting Spider/ Centre nipple/ bush in correct position.
10. Align holes in mounting spider with holes in junction box and attach with two mounting screws. Secure screws with a Phillips screwdriver.
11. Pull down the house/ junctionbox wire though the centre nipple for connection.
12. Carefully inspect the Chandelier's fixture wires.  
Neutral fixture wire: White  
Hot fixture wire: Black  
Ground wire: Green
13. Attach the Ground wire from the Chandelier to the Ground junction box wire (usually Green). Fasten each together with a Plastic Wire Connector and wrap the connection with electrical tape.
14. Attach the neutral fixture wire from the Chandelier to the neutral junction box wire (usually white). Fasten each together with a Plastic Wire Connector and wrap the connection with electrical tape.
15. Attach the hot fixture wire from the Chandelier to the hot junction box wire (usually black). Fasten each together with a Plastic Wire Connector and wrap the connection with electrical tape.**DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
16. Then push the canopy to the mounting spider & attach the 4 screw back & also screw the bush back to complete the electrical assembly.
17. Insert 01Type A 40W bulbs into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
18. For glass assembly, insert the glass on the socket cup & tighten the screw, then put the iron bowl on the socket cup & tighten the bush ring in clock wise direction.
19. Restore power to junction box and test fixture. **DO NOT EXCEED SPECIFIED WATTAGE OF PENDANT.**

### **CARE INSTRUCTIONS**

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.