

Wall hanging installation method

01



Install the expansion screw into the wall

02



Hang the screws into the dovetail hook

Paste, install, and use

01



Wipe the wall clean with a dry cloth

02



Apply a sufficient amount of nail free adhesive evenly on

03



Evenly press the flat surface to expel air

04



Wait for 72 hours for complete solidification before hanging