

Installation Steps:

1. Plan Your Layout

- Decide the pattern/layout (square, diamond, fan, etc.) you want for your wall.
- Mark the positions where each wire holder will go — use a level for even spacing and straight alignment.

2. Mount the Adjustable Holders

- Drill pilot holes at the marked spots.
- Insert wall anchors if installing into drywall, brick, or other masonry surfaces.
- Screw the wire holders securely into place.

3. Feed the Wire

- Cut the stainless steel wire rope to your desired lengths using a wire cutter.
- Slot the wire into the holders as per your pattern.
- Insert the wire into the adjustable set holder openings.


4. Secure and Tension

- Use the provided grub screws and Allen key to tighten the wire inside each holder.
- Adjust the tension as needed — holders allow wires to be spaced up to 2.5 inches off the wall for airflow and plant health.

5. Finish with End Caps

- Place the protective end caps over the wire ends to avoid sharp edges and maintain a clean look.

Tips:

- Start from one corner and work outward.
- Keep some slack initially; tighten after all wires are in place.
- Ideal for vines, climbing plants, or decorative green  walls.