

ASSEMBLY INSTRUCTION

LIST OF HARDWARE			QTY
	SCREWS	#8" 1. 2"	8PCS

1. Carefully place Mirror on the Dresser and line up center line.
2. Attach the two wooden Mirror supports to the Mirror and Dresser using the wood screws provided.

