

## Assembly Instructions

Read all instructions before starting assembly:

**Step #1** Remove all the contents from the package checking that all of the components listed in "Packaged" are included. Prepare a flat, protected work surface where the product can be assembled.

**Step #2** Place **Credenza** (A) on its back, (Drawer will be up) and align one Turned Foot (B) with threaded insert hole in the bottom and screw into tightened position. Repeat procedure for remaining feet.

**Step #3** Place **Credenza** into upright position.

(\*Caution: Do not overtighten.

In any correspondence regarding this product, please include the complete identification number located on the underside of the product.

We hope that this **Credenza** will be a useful and decorative addition to your home for many years to come.

### SPECIAL NOTE:

FEET ARE PACKAGED INSIDE  
DRAWER. REMOVE FIRST BEFORE  
PLACING UNIT ON ITS BACK.

### PACKAGED

- (A) 1 - **CREDENZA**
- (B) 6 - **TURNUED FEET**

