

Shoe Cabinet

Hardware Accessories				
No.	Spec & Name	Icon	Qty	Unit
A	3-in-1 Connecting Rod		72	pcs
B	3-in-1 Lock Shaft		72	pcs
C	Ø8*40 Wood Screw		36	pcs
D	Tapping Screw M3.5*14		140	pcs
E	Tapping Screw M3.5*30		20	pcs
F	Connecting Plate 50*28		2	pcs
G	Vent Cover Ø60*15		4	pcs
H	Layer Board Support Ø5		24	pcs
I	Large Angle Hinge		4	pcs
J	Medium Angle Hinge		4	pcs
K	Ø20 Foot Mat		5	pcs
L	Connecting Screw		2	pcs
M	12-inch Slide Rail		4	pcs
N	Steel plate foot pad		4	pcs
No.	Part Name		Qty	
1	lower plate		1	
2	Lower small middle side panel		2	
3	Upper Middle Side Panel		1	
4	Middle Back Panel		2	
5	Inner Stretcher		2	
6	Front Stretcher		1	
7	Outer Side Panel		2	
8	Side Back Panel		2	
9	Base Plate		1	
10	Side Foot		4	
11	Middle Foot		1	
12	Top Panel		1	
13	Upper small middle side panel		2	
14	Drawer Front Panel		4	
15	Drawer Side Panel		8	
16	Drawer Bottom Panel		4	
17	Drawer Back Panel		4	
18	Movable Layer Board		6	
19	Cabinet Door Panel		4	

3-in-1 Assembly Instructions

- The hole diameter on the side panel is Ø5; insert the screw rod directly into this hole.
- Insert the other end of the screw rod into the side hole of the other connecting plate, press the eccentric lock plate into the Ø15 hole, and ensure the cross arrow aligns with the side hole.
- Tighten the eccentric lock plate clockwise with a Phillips screwdriver.

