

How to **Install**



Simply drive the **included post anchors** into the ground with a **hammer** or **mallet**.