

ASSEMBLY INSTRUCTION TIP:

Due to the physical properties of textilene we recommend that you assemble the product at room temperature. Low temperature stiffens the sitting net which makes the assembly process complicated.