

Simple Bracket Shelves

Instructions



STEP 1

At desired height, level each bracket and with a pencil make a small mark at center notch of the top "Key-Hole" and lower hole of each bracket. Insert the supplied drywall anchors for each bracket into the wall. Insert the top screw into the wall anchor (do not tighten all the way in, leave a 1/4 inch exposed)



STEP 2

Align the bracket with anchor, use supplied 2" #6 phillip's head screw to mount the bracket to the wall (do not over tighten)



STEP 3

Center shelf on top of wall mounted brackets. Use the supplied 1" #6 phillip's head screw to secure the shelf to the bracket.

