KEONJINN

Easy French Clet Mounting



Step1: Fixed Hanging Bracket



Step2: Plug in or
Cut the Plugand Hardwire



Step3: Hang the mirror



Expansion
Drywall Anchors
Thickness of Wall:
>5/8"



Butterfly
Drywall Anchors
Thickness of Wall:
5/16"-5/8"