

HOW TO CHOOSE YOUR ROD LENGTH

1 GRAB A TAPE MEASURE AND A PENCIL.



2 MARK ROD OVERLAP IN BOTH ENDS.
OVERLAP IS NEEDED FOR SINK BACK CURTAINS.



3 FOR OVERALL LENGTH OF POLE NEEDED MEASURE DISTANCE BETWEEN MARKS.

