

Golden Margined Century Plant

Assembly Instructions

English

(Planter Purchased Separately)

- 1 Open tree box, remove cardboard inserts, cut strings used to tie the plant, take out of the plant and a bag of rocks.



- 4 Put the entire plant into the hole of the pot, and adjust the tree to a good position.



- 2 Open pot box, remove foam and polybag, and take out of the pot (Planter Purchased Separately).



- 5 Take out the rocks and put around the hole of trunks.



- 3 Remove the bubble bags and take off the polybag from top.



- 6 Begin shaping your leaves by bending them from the bottom up to give them a natural curved shape.