

QUICK INSTALL



Put the blind into the window frame



Tighten the nut firmly by hand and wrench



Slide the lid on and done

Measure inside Mount

Window depth ≥ 1.6 Inches

Blind width = Window width - 0.25 ~ 0.5 Inches

Blind height = Window height + 2 Inches

