

ASSEMBLY INSTRUCTIONS:

1. CAREFULLY UNPACK PARTS FROM CARTON, REMOVE COVERING FROM PARTS AND CHECK THAT ALL PARTS ARE INCLUDED AS SHOWN IN THE ILLUSTRATION.
2. SECURE THE SCREWS (8) THROUGH WASHERS (7) INTO BASE(6) (HOLES SHOULD BE ALIGNED), ONTO POLE (5), THEN PULL OUT WIRE (9).
3. REMOVE SOCKET RING (2) FROM SOCKET (4), PLACE SHADE (3) ONTO SOCKET (4) THEN SECURE WITH SOCKET RING (2).
4. SCREW BULB (1) INTO SOCKET (4).

**USE 23W CFL TYPE BULB OR 100W (MAXIMUM)
INCANDESCENT A TYPE BULB**

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

ATTENTION

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES À FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT

✘PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

✘SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

