

MODE® Premium Adjustable Single Rod Sets

INSTALLATION INSTRUCTIONS

INSTALLATION FOR 144" TO 240" ROD WIDTHS:

- 1 Determine the placement of rod(s) using the Measuring Guide.
- 2 Measure and mark bracket locations above window, evenly spaced apart. Utilize a level to ensure the rod will be level on the wall.
- 3 Drill 9/32" diameter pilot hole in drywall (or 1/8" in stud) for all marked bracket locations. For drywall only: Hammer plastic anchor into pilot hole until flush.
- 4 For **144" to 240"** rod widths, use four brackets. Refer to Measuring Guide Diagram. Assemble rods per the Telescoping Rod Assembly diagram. Follow steps **4a.** and **4b.** below.
 - 4a Attach wall brackets A to wall using wall mounting screws. Hand tighten with screwdriver only to prevent screw head damage. **(Fig. 1)**
 - 4b Place rod brackets B onto wall brackets A. Adjust to desired projection and tighten using set screws. **(Fig. 2)**
- 5 Slide drapery panels or rings onto the telescoping rod and place rod into the rod cups on the installed brackets, spacing panels evenly between brackets. Tighten set screws to secure the rod. **(Fig. 3)**
- 6 Attach decorative finials onto each end of the rod. **(Fig. 4)**

