



**FLAT TRACK**  
BY LEATHERNECK HARDWARE

## Wall Guide Installation

1. Set the door so that it is plumb & level.
2. With the guide against the wall & beside the door decide if you want a fin or cradle type guide. The fin type requires a mortise  $\frac{3}{8}$ " wide x  $\frac{1}{2}$ " deep in the bottom of the door. The cradle type uses one fin in front or both fins to hold the door on each face.
3. Once you've made your choice simply adjust or remove fins accordingly with the provided Hex L-key.
4. Locate the middle of the track at the bottom of the door.
5. Install the bracket onto the wall at that location making sure the door is in place according to your guide type.

