HEADREST ASSEMBLY INSTRUCTIONS



| PART | QTY |
|------------------------------|-----|
| 1. Headrest | 1 |
| 2. Small Screws | 2 |
| 3. Allen Wrench (packed with | |
| chair hardware) | 1 |

Remove all parts from carton, separate by part numbers indicated on parts list, and verify part quantities.

STEP 1 Attach Headrest (1) to top rear of Back Assembly using two Small Screws (2).

FULLY TIGHTEN <u>ALL</u> SMALL SCREWS (2) USING ALLEN WRENCH (3).

ATTENTION: MAKE SURE ALL SCREWS ARE FULLY TIGHTENED BEFORE USING CHAIR.