

Read carefully before application. Thank you for purchasing Timeline Shiplap.

There are a variety of ways that this product can be applied but the best method for a secure installation is to use panel adhesive on the back of the board and nail with a small brad nail. Here is an overview:

#### NAILING:

Nailset Method: You can use a hammer and panel nail or for faster installation, use a pneumatic brad nailer or micro nailer.

When nailing over a substrate such as drywall, you should purchase a nail that will penetrate the thickness of the shiplap, drywall, and then into a framing stud if possible. If you can't nail into a framing stud, this is where panel adhesive helps. You do not have to use panel adhesive but it will help provide a more secure installation.

#### PANEL ADHESIVE:

Wood planking may be applied over 1/2" shearing gypsum or wood with a paneling adhesive. Follow the adhesive manufacturer's suggested instructions in regard to the proper application of the adhesive. Apply small dots of your Fast Setting Panel Adhesive on the back of the board. Apply the board to the wall and nail.