

CHIC TEAK

Assembly Instruction

INSTRUCTION DE MONTAGE
MONTAGANLEITUNG
SAMLEVEJLEDNING

**MAKE SURE THE LETTERS
MATCH BEFORE ASSEMBLING
NEED ASSEMBLY ASSISTANCE?
CALL US AT 866-814-8325**



**Make sure to use Gorilla Glue (Not Included)
on all wood joints before assembly**

Code

HJ085

Hardware



Screw (8 Pcs)

Tool

Total Section

3 Section