

## **Installation Instructions CT1711W**

- 1) Screw the mountain bracket onto wall that has supporting to hold the heavy sink
- 2) Place the back part of the sink onto the bracket and screw the two heavy screws into the two bolts of the sink
- 3) Glue the sink to the wall with silicon for extra support.

Note: All screw has to be drilled into a beam or anything that could hold this heavy sink.