



Note: It is best to assemble this item on its side for an easy installation.

Slide Part "C" onto Part "H". Install Part "A" underneath Part "C". (See Picture 2)

Next attach Part "D" and Part "B" to Part "H". (Picture 3)

Attach the nut (Part "E") to the exposed portion of Part "H" underneath Part "B" (Picture 4)