



POST MOUNTING

CAUTION: Turn off electricity at main electrical box BEFORE installation.

1. Place Lantern with POST-HOLDER over POST, and align Lantern to desired orientation.
Mark hole locations of POST-HOLDER onto POST.
Remove Lantern and drill the 3 holes with a #29 or 1/8" drill bit.
Use the self-tapping screw provided to thread the 3 holes.
2. •Connect the identified (ribbed) wire to the white (neutral) wire from the outlet box.
•Connect the smooth wire to the black (hot) wire from the outlet box.
•Connect the GROUND wire of Lantern to GREEN or Bare wire from outlet box.
•Use wire nuts and electrical tape to make all connections.
3. Place Lantern onto POST, align holes and fasten with the 8-32 thumb screws provided.

WARNING: RISK OF FIRE. Most dwellings built before 1985 have wire rated 60 C. Consult a qualified electrician before installing.

CAUTION: Use light bulbs with wattages no greater than specified on fixture. Make sure electricity is off BEFORE installing light bulbs.



4509 LITTLE JOHN STREET, BALDWIN PARK, CALIFORNIA 91706