

Simple Installation Instructions for **L-Shaped Corner Desk**

1. Lay the L-shaped desktop upside down with the drawer side resting on the floor. Keep the finished top surface facing downward for easier screwing and bracket installation.



2. Align the two hollow rectangular frame brackets with the pre-drilled mounting holes on the bottom of the long edge and the short corner edge of the L-shaped desktop respectively, then secure them tightly with self-tapping screws.



3. Attach the long single leg to the bottom of the outermost extended corner end of the desktop to complete the three-point support system.



4. Carefully flip the entire desk right-side up and set it on a level surface. Check that all supports bear weight evenly and the desk does not wobble or loosen to finish installation.

