ASSEMBLING INSTRUCTION

TABLE FOR LOUNGE CORNERSET 6-PCS

Α		1рс
В		4pcs
С	(d)))))))))) M6*20	16pcs

D	Ø6	16pcs
Е		1pc

Note: first screw all bolts in by hand, before tightening.

