

- Using the included allen wrench, remove the screws on the underside of the train rack. There is one screw on each side.
- Once the screws are removed, the mounting brackets and bracket covers will come free from the train rack.
- Using the included screws, mount the brackets to the wall.
  - If you are mounting directly to a stud, you do not need to use the included drywall anchors.
  - If you are not mounting a stud, then drill a small hole into the drywall and gently hammer the anchor into it. Then screw the bracket into the anchor.
- Place the bracket cover over the bracket.
- Place the train rack on the mounting brackets. Replace the screws on the underside of the train rack.