ASSEMBLY INSTRUCTIONS LADDERBACK STOOL WITH UPHOLSTERED SEAT

NO.	. Parts List		Q' TY	NO.	Hardware list		Q' TY
A		Chair Back	1	1	()	5/16"*3-1/8" Allen Bolts	4
В		Chair Seat	1	2	©	5/16"*2-1/4" Allen Bolts	4
С		Front Leg (Right)	1	3	(1)	5/16"*1-1/2" Allen Bolts	3
D		Front Leg (Left)	1	4		Spring Washers (8mm)	11
E		Side stretcher (Right)	1	6	(f)	Flat Washers(8*19*2mm) #8x 1-1/2" Wood Screw	6
F		Side stretcher (Left)	1	7		Allen Key (4mm)	1
G		Front stretcher	1		7	® STEP 1	
STEP 2 STEP 3							
Page 1 of 1						MADE IN VIET	NAM