

INSTRUCTIONS:

1. Remove existing showerhead from shower arm.
2. Apply thread sealant tape to existing shower arm threads.
3. Thread 3 way diverter onto existing shower arm hand tight plus a quarter turn with a wrench.
4. Apply thread sealant tape to outlets of 3 way diverter's threads.
5. Thread new showerhead onto diverter hand tight plus a quarter turn with a wrench.
6. Insert washer between one end of the hose and the diverter. Hand tighten hose to diverter.
7. Insert remaining washer between handheld showerhead and hose. Thread new showerhead onto hose and hand tighten.
8. Slide hose and showerhead through diverter bracket and seat the showerhead into the diverter bracket.

Diverter operation:

Adjust diverter knob to change water flow from the showerhead to handheld shower, or both.

Tip: Use cloth between wrench and nut to protect finish.