Instructions

1,Ruler measures good length, convenient wall nail,Use

a tape measure to measure the distance between the two mounting holes on the back of the antler hook and record this dimension



Measure the distance between the two holes



Use a pen to mark the two sides of the Clothes Hanger that has just been measured.



Mark the hole position on the wall, and mark 2 horizontally aligned holes on the target wall according to the measured distance with a marker pen



Finally, hang the hook on the nails that have just been knocked into the two sides of the wall.



Reference is shown below

The required tools

Tape measure

Marker pen

Electric drill (with a drill bit matching the size of the plug)

hammer

Screwdriver

Packaging accessories

Antler hook × 1

Wall plug × 2 (matching with the hook installation hole)

Screw × 2

3 Installation Steps

Measure the distance between the installation holes

Measure the distance between the two installation holes on the back of the antler hook with a tape measure and record this dimension.

Mark the drilling positions on the wall

On the target wall, mark two horizontally aligned drilling points with a marker pen according to the measured distance

Drill holes in the wall

Select a drill bit that matches the size of the bridge plug. Drill vertically into the pipe wall at the marked position (the depth of the drill should be slightly longer than the length of the pipe wall plug).

Insert the plug into the wall

Insert the wall plugs into the drilled holes and gently tap them with a hammer until they are fully embedded in the wall.

Fixed hook

Align the installation hole of the antler hook with the wall plug on the wall. Pass the screw through the hook hole and tighten it with a screwdriver to complete the fixation

Attention

Before drilling, make sure there are no water or electricity pipelines inside the wall to avoid potential safety hazards.

It is recommended to install on solid walls (brick walls, concrete walls). Special anchor rods are used for hollow walls.

After installation is completed, gently pull the hook to test its stability. Don't hang too heavy items.


Measure the distance between the two mounting holes
Mark two horizontally aligned drilling points
Clear Broncj Duving Rrincıment ts Image 5
Step 4: Insert the expansion tube into the hole and tap it gently with a hammer until it is fully embedded.
Step 5: Align the mounting holes of the antler hook with the expansion tubes, and tighten the screws with a screwdriver to fix it.
HOU! SOVE BRALEN GUTE SATS