



Once you open the box you'll notice the chair in 2 pieces. There is a bottom piece which is the seat portion and the top piece which is the back of the recliner. Remove the foam wrap from around the hardware posts on the bottom piece.

Locate the KD Brackets on the bottom of each side of the back of the recliner. The brackets slide on the hardware posts and lock into position. You will hear the bracket lock once it is in place.

