

There are no pre drilled holes.

Step 1. Simply place the legs in the spot you would like them and mark the holes with a sharpie.



Step 2. Using a power drill, pre-drill holes where the sharpie mark is. This is only a starter hole. Only drill a small hole.



Step 3. Screw legs in. Then turn over and enjoy.



