

Twin 48" (3/4) Full Bed Frame

1. Remove the two sides of the frame and lay them on their side. They are not side specific or end specific.

2. Swing the cross arms open as shown. Lay the frame open as shown.



3. Swing the cross arms out toward the center of the frame so they touch. The arm with the hole will be over the top of the arm with the slot. You will need to line up the appropriate hole & slot to give you the proper width of the bed.



Counting from the leg in, use the second slot (middle slot) & the third hole for 48" 3/4 bedding. For a twin bed, use the first slot (closest to the leg,) and first or second hole closest to the leg. For a Full bed, use the second (middle slot) and the fourth or fifth hole from leg.



In whichever hole the slot lines up, insert the 5/16 carriage bolt from the inside out, meaning the square neck of the bolt will be in the slot. Then, thread on the nut and tighten with the wrench provided.

4. Now put the black glides/feet on all 4 legs. So, at this point, the frame should look like this.



Twin 48" (3/4) Full Bed Frame

5. If you are using a headboard, find the headboard mounting brackets. They can be used as either left or right. Pick a set of the round holes that look like the right height for the headboard mounting holes. Loosely attach the brackets to the frames as shown. Hold the headboard up to the frame and see if you have selected the proper holes. Once you have selected the proper holes, tighten the bracket. The brackets can be turned in or out, or one can be turned in and one out. Whatever configuration you need to securely attach the headboard.

