

## ASSEMBLY INSTRUCTIONS:

### VERY IMPORTANT:

**PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS.**

**NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY**

1. Carefully unpack and place all lamp parts on a flat surface.
2. Screw Tube (B) onto Base (A) until snug.
3. Screw Tube (C) onto tube (B), then screw Tube (D) onto Tube (C) until snug.
4. Screw Assembly Socket (E) onto Tube (D) until snug.
5. Screw Rod (F) onto Assembly Socket (E) until snug.
6. Place Inner Shade (G) and Outer Shade (H) onto Rod (F), then put Diffuser (I) onto the shades and secure with Metal Finial (J).
7. Install two bulbs (not included) into sockets.
8. Insert the polarized plug into a wall outlet and enjoy.
9. Use only a soft dry cloth to clean. Never use chemical or abrasive cleaners.

**Use two 60W (Maximum) A type incandescent bulbs or 13W CFL type bulbs.**

## IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.

### ATTENTION

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES À FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

