



• Screws*2

Drywall Anchors*2



• Hanging Hook

INSTALLATION STEPS



Make the location
where your mirror
going mount



Screw the anchor into
the wall with a
screwdriver until the
head of the anchor
is flush with the drywall



Insert the philips
screw and align the
screw tip to the cross
center of the drywall
anchor, tighten with it