



Drill hole position,  
template included



If using toggle bolts: **5/8" Drill Bit**  
If using plastic anchors: **3/4" Drill Bit**  
For cement walls: **Masonry Drill Bit**

- **Mark the Position:** Use a measuring tape to determine the desired height for the rack, typically around 1.5 - 1.8 meters from the floor for easy access. Mark the positions on the wall where the brackets will be installed. Ensure the marks are level using a spirit level.
- **Drill Holes:** Drill holes at the marked positions. The depth of the holes should be suitable for the wall plugs provided in the kit.
- **Install Brackets:** Insert wall plugs into the drilled holes. Then, use screws to attach the brackets firmly to the wall. Make sure the brackets are tightly fixed.
- **Attach the Rack:** Hang the foldable laundry rack onto the installed brackets. Align the holes on the rack with those on the brackets and secure them with the provided screws.