

Easy to install



1

Clean the smooth surface and dry it



2

Peel off the protective layer



3

Adhesive it on the surface then press firmly for 30 seconds



4

Waiting for 24 hours before hanging