

# 5/8" DRAPERY ROD INSTALLATION INSTRUCTIONS - 26-48" DOUBLE ROD SET

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

**SET INCLUDES:**

A X8      B X8      C X2      D X1  
 Extends 26-48"

**YOU WILL NEED:**

1/4" dia.

**1**

Extends 26-48"

Before installation, measure windows to determine appropriate drapery rod length.

**2**

Drywall

Use bracket (C) or drilling template (see reverse) as a guide to mark location for mounting screws (A). Drill pilot holes with 1/4" drill bit (not included). Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs.

**3**

Repeat step 2 for additional bracket. Use level if necessary.

**4**

Place drapery panels (not included) onto smaller diam. telescoping drapery rod and extend to desired length.

**5**

Screw rod into back position of one end bracket.

Gather drapery panels to this end. Extend rod to desired length and screw into other end bracket.

Separate panels as desired.

**6**

Repeat steps 4-5 for front drapery rod.