

DESK

INSTALLATION INSTRUCTIONS

NOTE:

If there are nuts on the frame,
you need to unscrew the
nuts first.





All fittings before installation



Step 1

Install the top white frame of the cabinet, Use self-tapping screws to lock the holes



Step 2



**Install bottom gold frame and lock with self tapping screws
Then screw on the pads**



The cylindrical iron legs align with the table bottom screws and screw on the nuts

Step 3



Step 4



The white frame at the top of the cabinet aligns with the screws on the bottom of the table to tighten the nuts