

Steps For Installations

- 1:Measure windows &trim film .
- 2:Clean windows glass.
- 3:Wet the window glass with soap water.
- 4:Remove the films back cover(very important step) ,the window film cannot stuck if this stept ignored.PS: Affix tapes on both sides to move the backing film easily.
- 5:Install the films to glass.
- 6:Squeeze out water and air bubbles with a smooth tool, sunch as credit card.

Tips:If the corners of the window sticker are peeling, please remove the corners and repeat the spraying and operation for more times.