

Wall hanging installation method



Install the expansion screw into the wall



Hang the screws into the dovetail hook

Paste, install, and use



Wipe the wall clean with a dry cloth



Apply a sufficient amount of nail free adhesive evenly on



Evenly press the flat surface to expel air



Wait for 72 hours for complete solidification before hanging