


SLIDING DOORS TERRARIUMS INSTRUCTION MANUAL



7. Install top metal ventilation mesh and the 4 rubber caps on top of the screws to cover the screws.



Done!


WARNING

The distance between the plastic frame on top of the terrarium to the edge of the heat lamp metal dome must be a minimum of 1cm, this is to prevent the burning of the plastic frame from the heat of the heat lamp metal dome.




Thanks for choosing our company's products. In order to use this product properly and ensure its service life, please read the instructions book carefully before using it.

PARTS LIST




INSTALLATION INSTRUCTIONS


1. Install the threaded metal tubes provided to the base. Frist Check the Numbers and Arrow marks on the metal tube, And firmly screw the metal tubes in trun onto the base of the terrarium.




2. Place the two back supports to the left and right. And then place the front supports,please note that the front supports with double slot.



3. Istall back glass and side glass panels.



4. When all the four sides have been installed, place the top frame without the top metal ventilation mesh. Make sure that the top frame sits in properly.



5. Screw the 4 screws firmly onto the metal tubes and then fix the glass lock in the front glass panel.

