



Simple Installation Steps

1. Apply silicone around the vanity top.
2. Place and align the countertop carefully.
3. Let cure for 24 hours, then remove excess silicone.