

1,Clean and dry the stairs



2,Peel off backing adhesive film



3,Place on stairs Press firmly



Easy remove,no residue left

