

ASSEMBLY INSTRUCTIONS

Ax1	① x16	<p>1</p> <p>Twist screw(1) to connect (A) (B) (D) (E) to form the frame.</p>
	② x4	
Bx1		
	③ x1	
Cx1		
	④ x4	
Dx2		
	⑤ x8	
Ex2		
	⑥ x2	
Fx4	⑦ x2	<p>2</p> <p>To protect the fabric on (C) from scratching, put (6) in the corners of (C) as displayed, then insert the frame into (C).</p>
	⑧ x2	
Gx4		
	⑨ x2	
	⑩ x2	
	⑪ x2	
	⑫ x2	
	⑬ x2	
	⑭ x2	
	⑮ x2	
<p>3</p> <p>Remove (6).</p>		<p>4</p> <p>Pass Screw(1) through (5) (4) and the holes on (C) respectively, securing it on (E).</p>
<p>5</p> <p>Place (G) into (F), then twist screws to connect (2) and (F) to form the drawers.</p>		
<p>6</p> <p>To prevent tipping over, you could secure (8) on the wall, then twist screw(7) to connect (8) with (A) (B) (C).</p>		
<p>7</p> <p>Finished!</p>		
<p>8</p>		
<p>9</p>		
<p>10</p>		
<p>11</p>		
<p>12</p>		
<p>13</p>		

If there are any questions during the assembly process, please contact us. An video and description about the step you were stuck will help us to understand the problem quickly.