

INSTALLATION INSTRUCTIONS



Steps1

The cabinet is already a fully assembled finished product. Then, the gaskets should be found first.



Steps2

Fix the gasket in place using angle iron on top of the two cabinets.



Steps3

Place the tabletop in position and secure it with angle iron.



Steps4

The baffle is the same, fix it between the two cabinets with angle brackets.

