

**INSTRUCTIONS:**

1. Remove existing showerhead from shower arm.
2. Remove flange and existing shower arm by unthreading counter clockwise.
3. Apply thread sealant tape to the longer threaded end of the flexible arm.
4. Thread flexible arm through wall and into existing threaded connection behind the wall hand tight plus a half turn with a wrench.
5. Place the included flange over the arm and secure it up against the wall.
6. Apply thread sealant tape to outlet of flexible shower arm threads.
7. Thread showerhead onto flexible shower arm hand tight plus a quarter turn with a wrench.

To adjust height/angle simply move the showerhead/arm to the desired position.

**Tip:** Use cloth between wrench and nut to protect finish